KitchenAid[®]


5 QT. STAND MIXER - TILT HEAD ARCHITECT SERIES - GLASS BOWL

MODELS:

KSM150AGBCA0 (Candy Apple) KSM150AGBCS0 (Cocoa Silver) KSM150AGBRI0 (Raspberry Ice) KSM150AGBES0 (Espresso) KSM150AGBFP0 (Frosted Pearl)

07/24/2013 Part No. W10325324 Rev. C


COLOR VARIATION PARTS



COLOR VARIATION PARTS

Illus. No.	Part No.	Description	Illus. No.	Part No.	Description	Illus. No.	Part No.	Description
2	W10171586 W10384420 W10383627 W10477204	Motor Housing Candy Apple Cocoa Silver Raspberry Ice Espresso Frosted Pearl Trim Band Dark Platinum	4	W10171581 W10384429 W10383633 W10477198 W10239112 W10171583 W10384425 W10383631	Frosted Pearl Planetary Candy Apple Cocoa Silver Raspberry Ice	5	W10171589 W10384415 W10383623 W10477200 W10239121 W10171592 W10392122 W10403051	Frosted Pearl Pedestal w/Feet Candy Apple Cocoa Silver Raspberry Ice

BASE AND PEDESTAL UNIT




4

BASE AND PEDESTAL UNIT

Illus.			Illus.			Illus.		
No.	Part No.	Description	No.	Part No.	Description	No.	Part No.	Description
1		Literature Parts	8	9704329	Whip, Wire	15	103993	Screw, Latch Bearing
•	9709785	Use and Care Guide	9	9706626	Hook, Dough (Burnished)	16	24450	Link, Latch
2	W10220977	Ring, Thread	10	9709055		17		Lever, Latch
3		Beater. Flat	11		Latch, Link and Lever		9709280	Black
_	9707572	Beater, Flat (Burnished)			Assembly		W10608281	Silk Chrome
		, , ,			Black	18	16910	Pin, Hinge
4	W10154769	Bowl, Glass 5 Qt.		W10608282	Silk Chrome	19		Pedestal
E	2400020	(K5GB)	12	110679	Screw			(Refer to Color Variation
5	3400020		13	116241	Washer, Spring			Parts Page)
6	W10191926	Cap, Bowl Screw	14	8533912	Washer			3 ,
7	9709707	Foot	• • •	2200012				


CASE, GEARING AND PLANETARY UNIT



CASE, GEARING AND PLANETARY UNIT

Illus.			Illus.			Illus.		
No.	Part No.	Description	No.	Part No.	Description	No.	Part No.	Description
1		Gearcase Motor Housing	12	240026	Shaft, Vertical Center	28		Shaft, Center Agitator Assembly
		(Refer to Color Variation	13	240018-1	Pin, Agitator Shaft	29		Washer, Lock
2		Parts Page) Cap, Attachment Hub	14	9705443	Pin, Grooved	30	3400025	Screw
2		• *	15	4162324	Gasket, Transmission	30	9708652	Screw
	242765-2		16	67500-55	"O" Ring	31	3400203	
	W10163146		17	W10323378	•	32		Gear, Pinion
3	0=00101	Thumb Screw	18	************	Lower Gearcase	33	9706090	
	9709194				(Refer to Color Variation	34		Planetary
4	W10615629	Silk Chrome			Parts Page)			(Refer to Color Variation Parts Page)
4		Band, Trim (Refer to Color Variation	19	9708651		35	240285	Ring, Planetary Drip
		Parts Page)	20		Shaft, Agitator			(Standard)
5	W10323373	Washer, Fiber	21		Ring, Retaining	36	89411	
6	W10112253	Gear, Worm	22		Pin, Groove	37	9703904	Gear, Internal
7	240308	Bracket, Worm Gear	23 24	4162914				
8	9705444	and Bearing Pin, Grooved	24		Cover, End (Refer to Color Variation			
9		Gear, Pinion and Shaft			Parts Page)			
		•	25	311932				
10	9705130	Gear, Attachment Hub	26	3400022	Screw			
11	9709627	Gear, Center Bevel Pinion	27	240309-2	Worm Gear Bracket and Gear Assembly			

MOTOR AND CONTROL UNIT PARTS



MOTOR AND CONTROL UNIT PARTS

Illus.			Illus.			Illus.		
No.	Part No.	Description	No.	Part No.	Description	No.	Part No.	Description
1	110679	Screw	11	W10131078	Nut	24	116286	Spring, Seat-Cap
2		Washer, Spring	12	3180238	Washer, Felt	25		Spring, Cap
3		Lever, Speed Control	13	240769	Screw, Stator	26		Cap, Brush Holder
		Assy	14		Washer, Lock		3184212	• •
	9709276		15	3184176	Link, Speed and Cam Assembly		3184211	
		Silk Chrome	16	240205	Spring, Flat	27	W10068260	
4	3183680	Spring, Control Plate	17		Field Assembly, 120 Volt	28		Control Plate Assembly
5	9704324	Washer, Ball Bearing (Front)	18		Sleeve, Motor Stud			,
6	W10477035	Armature and Bearing			•	29	W 10330804	Governor Assembly
		Assembly, 120 Volt	19	W10380496	Brush, Cap and Spring	30	W10325124	Board, Phase Control
7		Washer, Spacing	20	9707926	Screw, Set	31		(120 Volt) Cord, Power
8	16998	Stud, Governor Drive	21	4162546	Brush Holder Assembly	01	W10164883	,
9	3180526	Bearing and Bracket Assembly	22	3179908	Housing, Brush Holder		W10325327	White
10	240775-1	Seal, End	23	240680	Insert, Brush Holder	32	3184609	Screw